


VHT Job Aid #1

How to Use the Solar Charger & Nokia Mobile Phone









Shows minutes of light

Desk lamp









Once you choose an item on the screen it will be **highlighted in black.**


Press the centre black button to select what is highlighted. Press the **Red End key any time** to cancel and start over at the home screen.



Inserting and Removing SIM 2 Card




Open the cover of the SIM-2 card slot.



Make sure the MTN name on the SIM card is facing up. Insert the card.


Push the card in, until it locks into place.

Close the cover.



Push the SIM card gently to eject.

Save Numbers and Names to the Contact List



Make—Pick Up—End a Call



To Make a Call:

On the home screen, enter the phone number. Press the **Green Call Key.** Select the SIM card to use.

Select Clear to erase a mistake

- To Pick Up a Call: Press the Green Call Key or, select Answer. The SIM card in use will show.
- To End or Reject a Call: Press the Red End Key.

View Missed Calls



Return Calls

To Call the Last Number Dialed: Press the Green Call Key 2 times To Call a Number Dialed or Received: Select Menu Select Log Select Dialed calls or Dialed numbers Select the number Press the green call key

Read an SMS



A new message alert will display on the home screen. Select **View**



Select Menu Select Messaging





Select Message Press Open